

ASSEMBLY INSTRUCTION

7173-GC2323-2515



A	B	C	D	E	F	G
4 PCS	4 PCS	4 PCS	6 PCS	68 PCS	3 PCS	4 PCS
H	I	J	K	L		
2 PCS	2 PCS	4 PCS	14 PCS	2 PCS		

FIG.
1,2,
3,4





FIG.
5,6,
7,8


















A	B	C	D	E	F	G
						
4 PCS	4 PCS	4 PCS	6 PCS	68 PCS	3 PCS	4 PCS
H	I	J	K	L	  	
						
2 PCS	2 PCS	4 PCS	14 PCS	2 PCS		

FIG.
9

